

Record and watch a program on your non-X1 DVR



xfinity XR11
Remote



- Start by going to channel 971, 977 or 978
- Touch **GUIDE** - a list of channels appears
- ← highlights Ch. 971, 977 or 978
- **OKAY**
- → access RECORD options
- **OKAY**
- ↓ access recording time and date settings
- **OKAY**
 - ↑ / ↓ adjust hour
 - → move to MINUTES selector
 - ↓ / ↑ change minutes (zero for start of hour)
 - → move to AM / PM selector
 - ↓ / ↑ select AM or PM
 - **OKAY**
 - ↓ select DURATION
 - ← / → increment / decrement recording duration
 - ↓ move to select a date to START
 - **OKAY**
 - ↓ / ↑ change start DATE
 - **OKAY**
 - ↓ move to SAVE options
 - ← / → select save option; default: until [recording] space needed
 - **OKAY**
- ↑ ↑ ↑ ↑ move to CONFIRM selector
- **OKAY** to confirm recording options

Choose recording times longer than expected run time to capture whole programs.